naNo TEDDY™ INSTRUCTIONS

www. playmatestoys. com

The object is to take care of your Nano Teddy, just like you would a real teddy. If you take good care of your Nano Teddy, it will grow up happy. Your Nano Teddy will change appearance based on its age, weight and health. If you neglect your Nano Teddy, the play will end prematurely and your bear will run away. It takes approximately one month to play with your Nano Teddy successfully.

CONTROLS

Cancel/Mode ○
Left Cursor ◁
Right Cursor ▷
Confirm □

There are two different modes for your Nano Teddy: Timer Mode & Play Mode

Remove the Activation Tab by pulling it straight out. Your Nano Teddy should now be activated. Before you go any further, you need to give your teddy a name and set the current time.

NAMING YOUR NEWBORN

To enter your new Nano Teddy's name, simply:
Press button ▷ to scan through the alphabet.
Press button ◁ to scan backwards through the alphabet.
Press button ○ to select a letter and move to the next blank space.

When you are done, press button □ to enter in your Nano Teddy's name.
After you decide on a name for your Nano Teddy it is very important that you set the current time. (Please note, you can only set the time before your Nano Teddy is born.)

SET THE TIMER

Press button ○ to enter Timer Mode.
Press button □ and hold until the numbers begin to blink.
Press button ◁ to advance the hour.
Press button ▷ to advance the minutes.
Press button □ to enter the time and start the Timer.
Press button ○ to go back to Play mode.

Now, sit back and watch the wonders of binary birth, (be patient, this takes a little time.)

SOUND ON/OFF

Press button ○ to enter Timer Mode
Press button ◁ to turn sound off (♪ on display disappears)
Press button ◁ again to turn sound on (♪ on display re-appears)
Press button ○ to go back to Play Mode

PAUSE FEATURE

Press button ○ to enter Timer Mode
Press button ▷ for at least 4 seconds to pause play (beating heart changes to pause symbol)
Press button ▷ again for at least 4 seconds to resume (pause symbol changes back to beating heart)
Press button ○ to go back to Play Mode
(NOTE: you must resume play to go back to Play Mode.)

TEDDY'S HEALTH ? ? ?

In order to take good care of your Nano Teddy, you must know what it needs.
To check your Teddy's Health:
Press button ◁ or ▷ to select the Health Icon on the screen.
Press button □ to confirm your selection.

Scroll through the Health section using buttons ◁ or ▷.
You can check the following:
- Discipline
- Food
- Happiness
- Age and Weight

(NOTE: Always check the health of your Nano Teddy when the alert icon is displayed. In the early stages of play you must pay close attention to what your Nano Teddy needs or it may run away after only a few hours of neglect - if it is sick or dirty, etc. You may also use the pause feature to decrease the chance of your Nano Teddy running away prematurely. Your Nano Teddy will not grow while play is paused.)

FEEDING TIME

All babies work up an appetite being born so you'll want to feed your newborn Nano Teddy right away.
To feed your binary bundle of joy:
Press button ◁ or ▷ to select the feeding icon on the screen.
Press button □ to confirm your selection.
Press button ◁ or ▷ to select the proper food.
Press button □ to feed your Nano Teddy.
(NOTE: You should not overfeed your Nano Teddy. You should monitor your teddy's food level and try to keep it around 3/4 full. Also, too much of one type of food is bad for your Nano Teddy so you should vary its diet. This should include a variety of foods from lots of healthy eats to occasional treats and sweets which will make your Nano Teddy happy.)

AGES 8 AND UP

Playmates

ASST. NO. 40130
STOCK NO. 40133

EXCLUSIVE DISTRIBUTOR: PLAYMATES TOYS INC.
611 ANTON BLVD., SUITE 600, COSTA MESA, CA 92626.
PRINTED IN CHINA.

CLEANING TIME

When your Nano Teddy makes a mess, you have to clean it up -- yuka-puk!
If you see some stinky digital droppings on your screen or if your teddy hasn't had a shower in a while, then it's time to clean your Nano Teddy .
Press button ◁ or ▷ to select the cleaning icon on the screen.
Press button □ to clean your Nano Teddy .
Repeat as necessary.

PLAY TIME

Playing with your Nano Teddy is very important.
You need to make it happy to grow up healthy.
Press button ◁ or ▷ to select the game icon on the screen.
Press button □ to start the game.

The object of the game is to press the buttons that correspond to the symbols (shown below) that are displayed on the screen in order to cancel them.

○ = ○
◁ = ○
▷ = ○
□ = ○

If you cancel all of them as they appear your Nano Teddy will be happy. If the symbols fill the entire screen the game is lost and your teddy will be sad.

SLEEP TIME

Your Nano Teddy must get plenty of rest; so at night you should put your Nano Teddy to bed. To put your teddy to bed:
Press button ◁ or ▷ to select the sleep icon on the screen.
Press button □ to confirm your selection.

DISCIPLINE

If your Nano Teddy starts to cry for no reason, then you must discipline your teddy.
(NOTE: Be sure to check the Health Icon first! Your Nano Teddy should be well disciplined, especially during the early stages of its life)
To teach your Nano Teddy to behave, you must:
Press button ◁ or ▷ to select the discipline icon on the screen.
Press button □ to confirm your selection.

MEDICINE

If your Nano Teddy gets sick, you must give your Teddy medical attention right away!
(NOTE: If your Nano Teddy will not play with you or will not eat even though it is hungry, then your Nano Teddy is, indeed, sick.)
Press button ◁ or ▷ to select the Medicine icon on the screen.
Press button □ to confirm your selection.

EXERCISE

In order to keep your Nano Teddy fit and healthy you should make sure it gets plenty of exercise. To make your Nano Teddy jump and exercise:
Press button ◁ or ▷ to select the exercise icon on the screen.
Press button □ to confirm your selection.

WEATHER

If you see bad weather approaching, or if it begins to thunder or rain outside, you should send your Nano Teddy inside for shelter. To shelter your Nano Teddy from a storm:
Press button ◁ or ▷ to select the weather icon on the screen.
Press button □ to confirm your selection.

ATTENTION ICON

If the attention icon is displayed, you need to check on your Nano Teddy.

SUCCESS

Be a good parent and take very good care of your Nano Teddy and it will grow big and strong and live a long life! If you neglect your Nano Teddy, it will run away from home.

To start a new Nano Teddy, have an adult use a pointed object to press the reset button on the back of the unit.

BATTERY REGULATION: Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

Includes 2 replaceable button cell batteries. Batteries are included for demonstration purposes only and may need to be replaced by the consumer.

AGES 8 AND UP

Playmates

ASST. NO. 40130
STOCK NO. 40133

VISIT Playmates WIDE WEB
www.playmatestoys.com